

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.Dawn-Ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: IMPREZA12-5DR  
FOR: 2012-2017 SUBARU IMPREZA 5DR  
EFFECTIVE: 5/7/15

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – M-6 x 5/8" Mounting Screws
- B) 4 – Flat Washers
- C) 4 – Lock Washers
- D) 4 – Hole Locators
- E) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **REMOVE TRUNK LINER (as shown in Diagram A)** to expose drilling area.
2. Place the Sportwing® on the decklid and center from left to right. Once in the correct placement, outline with grease pencil **(as shown in Diagram B)**.
3. Place the Sportwing® upside down on a soft cloth that will not scratch the painted surface. Find the four (4) provided paper hole locators and remove their paper backing to expose the adhesive. Locate the four (4) mounting holes on the bottom of the Sportwing® and place the cut out hole locator centered exactly over these four fastening holes **(see Diagram C on the back of sheet)**. A piece of masking tape can hold the hole locators in place. Making sure the hole locators do not move, flip the Sportwing® over and place it back onto the grease pencil marks you made in Step #2.
4. Using a 1/8" drill bit or similar size, drill a 1/8" pilot hole through the exact center of the hole locations marked on the hole locator through the top panel of the deck lid only. After drilling four (4) holes on the hole locator, and using a uni-bit **(NOTE: we suggest using a uni-bit for a cleaner cut)** you will need to open all four (4) 1/8" pilot holes to 7/16". Touch up edges of 7/16" holes using touch up paint.
5. After waiting for the touch-up paint to dry, place Sportwing® onto the outline you made in Step #2. Hold the Sportwing® onto the decklid (it may help to have an additional person hold it for you) and open the trunk to make sure that the four (4) holes line up to the four (4) mounting screws on the Sportwing®. If alignment is correct, peel off the red lining on the back of the Sportwing® to reveal adhesive tape. Carefully center the Sportwing® onto the grease pencil marks made in Step #2 and push down to adhere Sportwing® to vehicle.
6. Open deck lid (while Sportwing® may stick to vehicle, it is advised to still hold the spoiler or have another person hold it while fastening it to the decklid) and begin fastening the four (4) M6 5/8" screws with lock washer and washer attached. Once fastened, re-attach the trunk panel.
9. Clean up any metal shavings and you are done. Please call the TOLL FREE number at the top of this sheet if you have any questions, or if you would like information about other quality Sportwing products. Thank you for choosing Dawn Enterprises, Inc.

DIAGRAM A



DIAGRAM B



DIAGRAM C

